

MASSAGE

CONTROL CONFIGURATIONS



JET MASSAGE

Jet Massage System
Without Lights



Jet Massage System
With Lights



AIR MASSAGE

Air Massage System
Without Lights



Air Massage System
With Lights



DUAL MASSAGE

Dual Massage System
Without Lights



Dual Massage System
With Lights



MASSAGE INSTRUCTIONS



Jet Massage Control

For Hydro Jet Massage Systems

This function turns the jet massage system on and off. Press the button once to activate the jet massage system and once to turn the system off.



Air Massage/Lights Control

For Air Massage Systems, Jet Systems Lights, and Air Systems With Lights

This function is used to turn on and vary the flow rate of the air system. Push the button once to activate Hi and again for Medium, Low, and Off. If your hydro jet massage or air massage system is equipped with lights, a similar button will control the lights.



Minute Drain System Control

For Minute Drain Systems

This function engages the minute drain system. Push the button once to activate the minute drain and once to deactivate it.